


Installation Guide

Step 1: Unpack Projector

- A** Remove one projector and one installation kit box.
- B** Open the protective projector bag and remove the projector.
- C** Open the installation box and remove the mounting bracket, image, retaining ring and power supply.



Step 2: Insert or Change Image

- A** Un-thread the telescoping portion of the projector to expose the image placement area.
- B** Using the provided micro fiber cloth, insert the image into the projector backwards and upside-down of the desired orientation. If dust is noticed, use provided micro cloth to gently wipe off the optics and image.
- C** Using the cloth, insert the retention ring on top of the image to secure image in place.
- D** Thread on the telescoping portion of the projector.

Step 3: Mount Projector

- A** Use the included bracket mount or any standard 1/4" 20 mounting option to mount projector in desired location.
- B** Place projector into bracket. By rotating the bracket and projector, aim projected image to desired location then secure by tightening thumb screw and bracket screw.
- C** Focus image by rotating telescoping lens.
- D** To adjust the size of the image, move the unit closer to or further away from the desired location and adjust the focus accordingly.

